

[H]ardBASS

Audio Equipment

HD15

15" High-Definition Loudspeaker

User Manual

Table of Contents

Safety Information and Precautions.....	1
Specifications.....	1
Quick Tour.....	2
Media Player.....	3

Engineered in Brooklyn Heights, NYC.
200 Schermerhorn Street, Brooklyn, NY 11201

Safety Information:

Thank you for your purchase of the [H]ardBASS “HD15” High-Definition loudspeaker. Please exercise general care and responsible use when operating the HD15.

The HD15 loudspeaker is capable of producing significant, forceful BASS reproduction, causing the loudspeaker and objects near the loudspeaker to move.

Please ensure the HD15 is safely positioned before use.

Do not operate the HD15 if there is moisture, excess humidity, heat or water hazard present. Ensure the electricity supply is stable and the power cord is in good condition.

Precautions:


- Do NOT try to “Max out” your loudspeaker.
- If the **CLIP** light is blinking, lower the volume.

Specifications:

The **HD15** is a 2400W Bi-Amp 15” High Definition (HD) Loudspeaker. Full specifications can be found at www.hardbass.audio.

Quick Tour:

Welcome to the world of High-Definition audio. We hear you.



Adjustments to the sound can be made with the Treble and Bass controls.

Do not “Max out” Treble and Bass knobs at high volume.

Note the **CLIP** light.

When the **CLIP** light blinks, lower volume.

For optimal performance, set the volume knob **well before** the point where the CLIP light indicator blinks. This ensures the best sound quality and most reliable operation.

Do not raise Treble or Bass controls past the 3 o’clock position for music playback at high volumes.


*Do not send high signal levels into the HD15. High signal levels are usually indicated by levels “going into the red” on your mixer or equalizer.

*Do not plug line-level sources (such as a Mixer) into “Mic1” or “Mic2”.

*Home stereo sets, car audio equipment, and Aux Sends (on mixing boards) can send high signal levels and damage your loudspeaker.

Media Player:

The [H]ardBASS HD15 is equipped with a comprehensive built-in media player.



Press the **"MODE"** button to switch between functions.

(1) MP3 Player Mode.

The HD15 can play USB Flash drives or SD cards loaded with MP3 files. **Folders can be skipped with the FD+ / FD- buttons.**

(2) Bluetooth Audio Receiver mode. Once enabled, sync to your phone or tablet. The icon changes once connected.

(3) Digital FM Radio.

To use the radio, first place the HD15 where there is best FM reception (outdoors on a tripod stand is ideal).

Press the Play button to begin scanning for FM stations. The scanning process may take a minute or two. Once scanning is complete, press >> or << buttons to change stations.